



**INSTRUCTIONS
HOW TO PLAY**

Open the back of Hot Potato and turn the...

SWITCH TO 'PLAY': Toss the Hot Potato back and forth, and pass it on before the music stops!

SWITCH TO 'NORMAL': Sing along to the Hot Potato, Hot Potato Song!



INSTRUCTIONS: HOW TO PLAY

Open the back of Hot Potato and turn the...

SWITCH TO 'PLAY': Toss the Hot Potato back and forth, and pass it on before the music stops!

SWITCH TO 'NORMAL': Sing along to the Hot Potato, Hot Potato Song!

INSTRUCTIONS: COMMENT JOUER

Ouvre l'arrière du Hot Potato et tourne le...

COMMUTATEUR À « PLAY » : imprime au Hot Potato un mouvement de va-et-vient et passe-le à quelqu'un d'autre avant que la musique ne s'arrête !

COMMUTATEUR À « NORMAL » : Chante en même temps la chanson Hot Potato Hot Potato !